

### Installation instructions for L P Gas steps

- 1 Remove the existing tank steps.
- 2 Adjust the bottom step to be 250 mm above ground level
- 3 Adjust the spacing between additional steps to 250 mm
- 4 Fix the new steps to the tank using supplied nut, bolt & washers (Fig 1)
- 5 Adjust the steps so the landing to tank is a max 100 mm (Fig 1)
- 6 Level the landing and secure leg adjustment bolts
- 7 Use the leg adjustment to correct uneven ground levels
- 8 Fix three legs to concrete or bitumen (50 mm x M12 masonry anchors)
- 9 If installed on gravel install pavers or foundations into the ground
- 10 Free standing steps must only be installed on a concrete foundation
- 11 Fix a "Warning Walk Down Steps Backwards" sign to the tank. (Fig 2)
- 12 Fix a "Warning Walk Down Steps Backwards" sign to the steps. (Fig 2)
- 13 Instruct the site operator regarding walking down the steps backwards



Figure 1



Figure 2